Name: Sudip Basu

Department: Computer Science and Technology

Roll: 16

Semester: 4th

COMPUTER NETWORK ASSIGNMENT


DNS server confguration in Packet Tracer

A Domain Name System (**DNS**) server resolves host names into IP addresses. Although we can access a network host using its IP address, DNS makes it easier by allowing us use domain names which are easier to remember. For example its much easier to access google website by typing http://www.google.com as compared to typing http://208.117.229.214. In either case, you'll access google website, but using domain name is obviously easier.

Now, before any host can use a DNS service, we must configure a DNS server frst. For example, when you type the URL http://www.google.com in your browser, the host will query the DNS server for the IP address of http://www.google.com. The DNS server will resolve http://www.google.com into an IP address then answer back the host with the IP address.

Now let's confgure a DNS server in Packet Tracer.

1.Build the network topology.




2. Confgure static IP addresses on the PCs and the server.

Server

IP address: 192.168.1.2 Subnet mask: 255.255.255.0 Default gateway: 192.168.1.1


DNS Server: 192.168.1.2



PC₀

IP add: 192.168.1.3 Subnet mask: 255.255.255.0 Default gateway: 192.168.1.1 DNS


server: 192.168.1.2



PC1

IP address: 192.168.1.4 Subnet mask: 255.255.255.0 Default gateway: 192.168.1.1

DNS Server: 192.168.1.2



3. Configure DNS service on the generic server.


To do this, click on the server, then Click on **Services** tab. Click on **DNS** server from the menu. First turn **ON** the DNS service, then define **names** of the hosts and their corresponding **IP** addresses.

For example, to specify the DNS entry for PCO: In the name and address felds, type:

Name: PC0 Address: 192.168.1.3

Click on add then save. Repeat this for the PC1 and the server.

Once you're done, your DNS entries will look like this:



Finally,

4. Test **domain name – IP resolution**. Ping the hosts from one another using their names instead of their IP addresses. If the DNS service is turned on and all IP configurations are okay, then ping should work.

For example, ping PC1 from PC0. Ping should be successful.

